


fast recovery rectifier diodes < 100 A

diodes de redressement rapide < 100 A




Types	I_O (A)	V_{RRM} (V)	I_{FSM} 10 ms (A)	V_F / I_F max (V) (A)	I_R / V_{RRM} max (μ A)	t_{rr} max (ns)	Case
-------	--------------	------------------	---------------------------	-------------------------------	--------------------------------------	-------------------------	------


100 mA / $T_{amb} = 25^\circ\text{C}$ $T_j = 125^\circ\text{C}$

PR 05 PR 11 PR 21 PR 31 PR 41	0,1	50 100 250 350 450	30	1	0,1	2	1000 (1)	 F 126 plastic/plastique (CB-210)
---	-----	--------------------------------	----	---	-----	---	----------	---

400 mA / $T_{amb} = 25^\circ\text{C}$ $T_j = 125^\circ\text{C}$ $C_o = 35 \text{ pF} @ -10 \text{ V}$

MC 22 MC 42 MC 43 MC 44 MC 45	0,4	100 200 300 400 500	3	1	0,4	100 $T_j = 100^\circ\text{C}$	200 (2)	 DO 7 glass/verre (CB-26)
---	-----	---------------------------------	---	---	-----	----------------------------------	---------	---

400 mA / $T_{amb} = 25^\circ\text{C}$ $T_j = 150^\circ\text{C}$

* BA 157 * BA 158 * BA 159	0,4	400 600 1000	30	1,5	1	5	300 (1)	 F 126 plastic/plastique (CB-210)
----------------------------------	-----	--------------------	----	-----	---	---	---------	--

500 mA / $T_{amb} = 50^\circ\text{C}$ $T_j = 150^\circ\text{C}$

PY 206 PY 207	0,5	400 600	15	1,5	2	125 $T_{amb} = 125^\circ\text{C}$	300 (3)
------------------	-----	------------	----	-----	---	--------------------------------------	---------

750 mA / $T_{amb} = 50^\circ\text{C}$ $T_j = 125^\circ\text{C}$

PY 208-800 PY 208-1000	0,75	600 800	30	1,8	2	80 $T_{amb} = 125^\circ\text{C}$	350 (4)
---------------------------	------	------------	----	-----	---	-------------------------------------	---------

800 mA / $T_{amb} = 65^\circ\text{C}$ $T_j = 125^\circ\text{C}$ $ER_{SM} = 1 \text{ mJ}$

BY 406 A BY 407 A	0,8	350 600	20	1,55	2	125 @ $V_R = 300\text{V}$ 125 @ $V_R = 500\text{V}$ $T_j = 125^\circ\text{C}$	300 (5)
----------------------	-----	------------	----	------	---	---	---------


1 A / $T_{amb} = 25^\circ\text{C}$ $T_j = 125^\circ\text{C}$

PLQ 0,8 PLQ 1	1	80 100	20	1,1	1	500 $T_j = 100^\circ\text{C}$	50 (6)
------------------	---	-----------	----	-----	---	----------------------------------	--------

1 A / $T_{amb} = 25^\circ\text{C}$ $T_j = 200^\circ\text{C}$ $C_o = 40 \text{ pF}$

EQ 1	1	100	20	1	1	500 $T_j = 100^\circ\text{C}$	50 (7)
------	---	-----	----	---	---	----------------------------------	--------

1 A / $T_{amb} = 55^\circ\text{C}$ $T_j = 175^\circ\text{C}$

BYV 88- 200 BYV 88- 400 BYV 88- 600 BYV 88- 800 BYV 88-1000	1	200 400 600 800 1000	30	1,3	1	100 $T_j = 100^\circ\text{C}$	150 (8) 150 (8) 150 (8) 250 (8) 500 (8)	 DO 29 glass/verre (CB-126)
---	---	----------------------------------	----	-----	---	----------------------------------	---	---

1 A / $T_{amb} = 25^\circ\text{C}$ $T_j = 150^\circ\text{C}$

ER 2 ER 4 ER 6 ER 8	1	200 400 600 800	20	1,3	1	200 $T_j = 100^\circ\text{C}$	1500 (2)
------------------------------	---	--------------------------	----	-----	---	----------------------------------	----------

* Type number + suffix T : $t_{rr} = 300 \text{ ns}$ ($I_F = 10 \text{ mA} - I_R = 10 \text{ mA}$)
* N° de type + suffixe T : $t_{rr} = 300 \text{ ns}$ ($I_F = 10 \text{ mA} - I_R = 10 \text{ mA}$)

- (1): $I_F = 2 \text{ mA} - I_R = 2 \text{ mA}$ (5): $I_F = 10 \text{ mA} - V_R = 50 \text{ V}$
 (2): $I_F = 100 \text{ mA} - I_R = 100 \text{ mA} - I_{rr} = 50 \text{ mA}$ $dI_F/dt = -0,5 \text{ A}/\mu\text{s} - I_{rr} = 0,1 I_{RM}$
 (3): $I_F = 10 \text{ mA} - V_R = 50 \text{ V}$ $dI_F/dt = -0,5 \text{ A}/\mu\text{s} - I_{rr} = 0,2 I_{RM}$ (6): $I_F = 1 \text{ A} - V_R = 30 \text{ V}$
 $dI_F/dt = -50 \text{ A}/\mu\text{s}$
 (4): $I_F = 0,4 \text{ A} - V_R = 50 \text{ V}$ (7): $I_F = 1 \text{ A} - I_R = 1 \text{ A} - I_{rr} = 0,1 \text{ A}$
 $dI_F/dt = -20 \text{ A}/\mu\text{s} - I_{rr} = 0,1 I_{RM}$ (8): $I_F = 0,5 \text{ A} - I_R = 1 \text{ A} - I_{rr} = 0,25 \text{ A}$